
Technical Bulletin

Required field modifications to laser rack

This bulletin provides information on a required modification to the laser rack before -04 version of LM-L or LM-R can be used.

To protect the optical surfaces inside the white laser module, Christie has modified the design of the LOS to:

1. Seal the LOS and prevent dust ingress.
2. Supply filtered air to the white laser module.

To install the new system, remove the brackets (if installed) on the side of each laser module location in the rack.

Affected products

The following products are affected.

- CP42LH
- D4KLH60
- E3LH (laser module powered)
- Mirage 4KLH

Technical support

Technical support for Christie products is available at:

- North and South America: +1-800-221-8025 or Support.Americas@christiedigital.com
- Europe, Middle East, and Africa: +44 (0) 1189 778111 or Support.EMEA@christiedigital.com
- Asia Pacific
 - Australia: +61 (0)7 3624 4888
 - China: +86 10 6561 0240
 - India: +91 (80) 6708 9999
 - Japan: 81-3-3599-7481
 - Singapore: +65 6877-8737
 - South Korea: +82 2 702 1601
- Christie Professional Services: +1-800-550-3061 or NOC@christiedigital.com